

# ImpressArt®

## *"Aloe Vera Much" – Personalized Bracelet Cuff*

**Skill Level:** Intermediate

### **Tools & Supplies**

- Ergo-Angle™ Metal Stamping Hammer
- Steel Block
- Stamp Enamel Marker™
- Stamp Tape™
- Bracelet Stamp Guides™
- Willow™, Lowercase, 4mm
- Bracelet Bending Bar
- Bracelet Bending Pliers
- Dot Design Stamp, .5mm
- Bracelet Stamping Blank, 1/4", Aluminum
- Polishing Cloth, Paper Towel, or Clean Rag



### **STEP 1**

Rotate stamping block so it's positioned in a diamond shape. Place bracelet blank horizontally on stamping block. Secure bracelet stamp guide on the bracelet blank. Use the guide marks to evenly space out letters and align stamp impressions.

**TIP:** Use stamp tape to secure the bracelet blank to the stamping block so it doesn't move while stamping.

**TIP:** Write desired message directly onto the stamp guide and utilize the guideline marks for spacing.

### **STEP 2**

Place stamp on blank, above the corresponding mark on the stamp guide. Lightly drag stamp towards the guide until the stamp catches the edge of the guide. Hold stamp flat and firmly in place by anchoring the side of your hand on workspace. Then strike stamp once with medium force using Metal Stamping Hammer. Repeat to complete desired word. Remove stamp guide.

**TIP:** If the stamp has an ImpressArt logo, make sure it is facing you so that the impression is stamped in the correct direction.

**TIP:** Slightly tilt the stamp towards you while dragging the stamp towards the guide. Make sure you hold the stamp flat and firmly in place before striking the stamp.

**TIP:** Use the dot design stamp to separate words.

### **STEP 3**

Highlight impressions with Stamp Enamel. Wait 3-5 minutes and then wipe away the excess enamel from the surface of the blank.

### **STEP 4**

Use the Bracelet Bending Bar to bend the blank into a cuff shape. Place one end of blank into the channel with the stamped side facing up. Firmly place your thumb against the end of the bracelet to secure it in place. Using the palm of your hand, bend the bracelet half way around the bar until it forms a 90-degree angle. Repeat on the other side to finish shaping a bracelet.

### **STEP 5**

Use the Bracelet Bending Bar to bend the blank into a cuff shape. Place one end of blank into the channel with the stamped side facing up. Firmly place your thumb against the end of the bracelet to secure it in place. Using the palm of your hand, bend the bracelet half way around the bar until it forms a 90-degree angle. Repeat on the other side to finish shaping a bracelet.